
订成本,成本后尺寸:90*120mm,128g双铜 9U*12Umm







How to use Using as an emergency light. With 6V sealed lead-acid battery 1.Turn off the light. 2.Plug into AC outlets. (AC110-240V 50/60Hz) 3.The EMERGENCY LIGHT starts recharging its battery automatically. (Indicator on the switch is red during the charging, turns green after fully charged)

4.The EMERGENCY LIGHT lights automatically whenever power fails. 5. Charge fully for about 12 hours before the initial use. 6.Charge fully after using the EMERGENCY LIGHT before storage. 7.Charge fully at least every three months during storage. Warning 1.NEVER attempt to disassemble or tamper the EMERGENCY LIGHT. 2.NEVER insert metal objects between gaps or spaces of the EMERGENCY LIGHT.
3.DO NOT cover the EMERGENCY LIGHT with towels, clothes, ect. 4.DO NOT use the EMERGENCY LIGHT in damp locations or under high humidity. 5.DO NOT use or place the EMERGENCY LIGHT near heating devices or under direct This Appliance is intended to be used in household and similar applications -staff kitchen areas in shops, offices and other working environments, farm houses, by clients in hotels, motels and other residential type environments. Bed and breakfast type environments. Safety Instructions This appliance is not intended for use by persons (including children) with

reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction

concerninguse of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the

Cord replacement Instructions

If supply cord is damaged, it should be replaced by the service agent, manufacturer or similarly qualified person.





Emergency Light www.ibellsworld.com

5 6