

Instruction Manual DRY/SPRAY/STEAM/BURST IRON



ELECTRIC STEAM IRON

Read the manual carefully before use







Technology evolves at an amazing pace, surprising us with gadgets surpassing our imagination. To stay in sync with changing times and present customers with the latest innovations at affordable prices assert the competence of a company. iBell, the consumer durables brand from India, has earned the recognition and trust of millions of customers by presenting them with the newest in home appliances. The brand provides high quality, long-lasting products at favourable prices and effective after-service.

Unlike many other brands iBell has a wide variety of products under its label, ranging from electronics appliances to kitchenware. The brand is further diversifying its product lines in order to serve the overall requirements of a family.

التقنية تتطور تدريجيا بخطوات مدهشدة، يعجبنا بأدوات فوق خيالنا. الوقوف مزامنا مع تغيير الأوقات والعملاء الحديثة مع ابتكارات الحديثة بأسعار معقولة، وهذه هي تتأكد كفاءة الشركة. آيييل كعلامة التجارية لأدواتالمستهلك من الهند قد اكتسبت تقدير وثقة مليونات من العملاء بتقديمهم أحدث لوازم

المنزلية. تتوفر الشركة منتجات عالية الجودة وطويلة المدى بسعر معتدل و خد<mark>مات</mark> فعالة بعد البيع.

تتميز شركة آيييل من علامات تجارية أخرى بسلاسل المنتجات المتنوعة العديدة تحت علامتها التجارية تتراوح من منتجات الكترونية إلى لوازم المنزلية. وتنتوع الشركة خطوط المنتجات لكي تخدم جميع المتطلبات العائلية.

Page: 2



- 1. Spray Jet
- 2. Water input opening/Lid
- 3. Variable steam control
- 4. Temperature control
- Press-button "water spray"
- 6. Hold
- 7. Water tank
- 8. Cable with plug

- 9. Movable cable-fold-protection
- 10. Stand
- 11. Pilot light
- 12. Heat resistant plate
- 13. Ceramic soloplate
- 14. Marking for maximum water-level
- 15. Self-cleaning

Important Safeguards

- Connect steam iron with a correctly installed power point only (220-240V). Make sure that the voltage of your steam iron is in accordance with the voltage of your power supply.
- Pay special attention when using or near children.
- Unplug the appliance even during short-term absence.
- Do not use the dry steam iron if the appliance itself cable or the plug are damaged
- Do not immerse the steam iron into water.
- · Keep the cable away from hot steam plate.
- Let the steam iron completely cool down before storing.
- Always keep the instruction manual. In case the steam iron is given away to a third person instruction manual must be handed over-too.
- Note: Before first use test with an old tissue whether the steam plate and water tank are clean. Some parts have been slightly greased, thus smoke can raise during first

This should stop after some moments.

Before Use

Button steam / steam dry

The steam / steam dry button (6) must always be in "0" position in all situations before filling water into the water tank and/or the steam iron is disconnected from main power supply. Otherwise, water will go to bottom of the soleplate through the water tank opening and water will leak from the soleplate.

Remark: For steam level selection, please refer to Dry / Steam Function below.

Use

Remove the protection film from the steam plate before first use.

You can use your steam iron with usual tap-water. Should the water be harder than 17' dH, distilled or dematerialized water has to be used to increase the steam iron's life span.

Fill in water tank (for steam ironing)

Unplug the appliance and turn the steam control knob (3) to "0" position.

Fill water into the tank, but never exceed the maximum marking when the steam iron is placed horizontally.

Close the lid again.

Now connect the steam iron with a correctly installed power point.

Temperature control

Put the steam iron upright and select the desired temperature with the temperature control (4)

By doing so pay attention to the care symbols on the textiles:

- chemical fibres/synthetic
- nature fibres/silk/wool
- nature fibres/cotton/linen

Assort your steam laundry according to texture and corresponding steam temperature, iron the sensitive materials with the low steam temperature first as the steam iron gets essentially faster hot than gets cold.

The pilot light (12) indicates that the steam iron gets hot After the pilot light is off, the selected temperature has been reached and you can start ironing

Water Leakage Prevention

The temperature control dial (4) must be turned near it maximum level in order to facilitate steam ironing. In case water drops come out from the bottom of the soleplate, that's mean water cannot be totally transformed into array of steam completely owing to low temperature inside the soleplate, increase the temperature of the soleplate by dialing the temperature control dial (4) nearer the maximum level until it stops water leaking.

Functions Anti-Calc Water spray Anti-trip

To moist the steam laundry, press the water spray knob (5)

Dry / Steam

You can fix the steam intensity directly by turning the steam function "0" = steam dry; "1" = Medium steam "2"= maximum steam outflow.

Burst of steam

To moist the steam laundry, press the water spray button (6) fully

Attention: Only, use the steam push button when the steam iron has reached the steam or maximum temperature.

Do not press this button more than 3 times at once.

Follow the water leakage prevention procedure in case water drops come out from the bottom of the soleplate.

Keeping/Cleaning/Care

Switch the steam iron off (Put control (4)-position to minimum temperature see mark on water tank), and unplug. Put the steam iron upright and let it completely cool down. empty the water tank.

Remove residues from steam sole with a vinegar-water solution. Rub the cabinet with a moisted cloth and finally rub it dry.

Automatic electricity interruption for security

In case the installed thermostat gets out order the power supply will stop automatically to avoid the steam iron to overheat. In this case the steam iron has to be repaired by the service point.

Cleaning/Care

According to frequency of use it is recommended that you should monthly clean the steam iron-this will increase the steam iron's life span.

- Put the steam control knob (3) to no steam position.
- Fill the water tank half with water.
- Put the steam iron upright.
- Put the thermostat (4) to the "max"-position and connect the steam iron with the
- Wait until the steam iron is completely hot (the pilot light switches out).
- Unplug the steam iron.
- Hold the steam iron horizontally over the wash-basin.
- Now hot water and steam are coming out of the apparatus. Residues like e.g. chalk depositions (if available), should be washed away with the water coming out.
- Simulate the ironing move until the water tank is almost empty.
- Put steam function to no steam position and connect the steam iron with the mains.
- Put thermostat (4) to the "max"-position. Let the steam iron become hot again, The remaining tank water vaporizes and comes out through the apparatus.
- We recommend to move the steam iron over an old tissue during this process.

Technical data

Model No.: TP-13-02 VOLT: 220-240V.50Hz

WATT: 2400W



Environment friendly disposal

You can help protect the environment! Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal centre.



KERALA SERVICE CENTERS

I BELL ELECTRONICS

Aiwad Building.

Andamukkam

IDEAL IMPEX

Vattakkavam.

Erattupetta.

Mr. Reji mon

Murikkottil Building,

Ph: 0091 - 9544500832

8. ERNAKULAM DISTRICT

11. PALAKKAD DISTRICT ATS AGENCIES

4/35 Thekkumuri

Perinthalmanna Road.

Pattambi, Palakkad

Mr. Muhammed Salih

Ph: 0091 - 9895424348

Kollam.

Mr. Hariz

1. TRIVANDRUM DISTRICT 2. KOLLAM DISTRICT I BELL ELECTRONICS

Chandavila. Sainik School P.O. Kazhakoottam. Mr. Hassan

Ph: 0091 - 9387642302

Ph: 0091 - 8089225557 4. ALAPPUZHA DISTRICT 5. KOTTAYAM DISTRICT

GAYATHRI TRADERS Padanad PO Chengannur, Alappuzha. Mr. Gopan sankar Ph: 0091 - 8547500646

7. IDUKKI DISTRICT BLUE MAGIC SATVISION

Bennys Tower Near Bus stand Rajakkad, Idukki, Mr Johnson Ph: 0091 - 9447990540

10. THRISSUR DISTRICT KALINDI ELECTRO

SYSTEMS D/No:1/852 Kanimangalam, Thrissur Mr. Rajagopal Ph: 0091 - 9447728188

13. CALICUT DISTRICT 14. KANNUR DISTRICT

CREATIVE ELECTRONICS MP Complex Ovitty Road, Calicut. Mr Raiesh G K Ph: 0091 - 9544160008

1. SHIVASHAKTHI ELECTRONICS

West Perumal Tank Road.

Ph: 0091 - 09597586944

0091 - 09344999001

Town Hall Road, Madurai-625001

N.K.V.Complex,1,

Mr. Upendran

1. IDEAL IMPEX,

Bangalore. Mr. Satheesh Ph: 0091 - 09562155207

Kalasipalayam

IDEAL IMPEX Near Koyili Hospital, Kannur.

Mr. Saiesh.K.K Ph: 0091 - 9544510008

Mr. Rajan Ph: 0091 - 9447381991

SATELLITE SYSTEM 61/61A Mettur Road, Abhirami Theater ,Agenda International Building Frode Mr Mavilswamy

2. MEGA DISH ANTENNA

3. SANJEEV RADIOS

Saab Towers, 204 & 219 Oppanakara Street Coimbatore - 641001 Mr. Sanieev Sahhanathy Ph: 0091 - 09363115323 0091 - 04222394124

3. PATHANAMTHITTA DISTRICT

Chouka Jn. Punalur Mr. Muhammed Riyas Ph: 0091 - 9497540556

ARAMAM ELECTRONICS

6. KOTTAYAM DISTRICT

ALFA ASSOCIATES Near Anand Theater Kottavam. Mr. Abhilash Ph: 0091 - 9544180001

9. ERNAKULAM DISTRICT

I BELL ELECTRONICS IDEAL IMPEX Opp: Elavumkudy Jewellery, Puthumana Bldg Oushadhi Jn., Perumbayoor . Karimpatta Road, Pallimukku Cochin.

Ph: 0091 - 9544170001 Mr. Badusha Ph: 0091 - 9544500831

12. MALAPPURAM DISTRICT IDEAL IMPEX

Nazrath complex Naduvilangadi. Tirur. Mr Janeesh Ph: 0091 - 9544830005

15, WAYANAD DISTRICT

HI TECH ELECTRONICS Chalachilwal Bulding Main Road, Sulthanbathery Wavanad

16, KASARAGOD DISTRICT

On site

WARRANTY

Call Center For Kerala

www.ibellsworld.com

© 0484 3950555

CHINA MARKET Near Bus Stand, Kanhangad, Kasaragod Mr Shaii Ph: 0091 - 9249742522

SHOP SITE SERVICE IN TAMIL NADU

Ph: 0091 - 09942070855 SHOP SITE SERVICE IN KARNATAKA

SHOP SITE SERVICE IN ANDHRA PRADESH

1. IDEAL IMPEX.

No:32/711, HAL Colony, Gaiula Ramaram. Jeedimetla Hyderabad. 500055. Mr. Saidu Muhammed Ph: 0091 - 08142743070 0091 - 09061079955

SHOP SITE SERVICE IN NEW DELHI

Page: 7

1. HANEET ELECTRONICS. 38, Anguri Bag New Delhi. Ph: 0091 - 09871762939

Page: 6

PRODUCT RANGE



MULTIMEDIA SPEAKER



LED TV



TELEVISION



PORTABLE DVD



DVD PLAYER



CAR DVD PLAYER



CAR USB PLAYER



SUB ENCLOSURE



CAR AMPLIFIER



IRON BOX



MIXER GRINDER



SPEAKER



TRIMMER



EMERGENCY LIGHT



LED FLASH LIGHT

PRODUCT RANGE



GAS STOVE



INDUCTION COOKER



NON STICK ITEMS



KETTLE



FLASK



PRESSURE COOKER



CHOODARAPETTY



ENAMEL CASSEROLE



CEILING FAN



PEDESTAL FAN



WALL FAN



TABLE FAN





VACUUM CLEANER



HIGH PRESSURE CLEANER

Page: 8